

S60 (-09), 2006, B5254T4, TF-80SC
 AWD, L.H.D, YV1RH527062549552, 549552

6/11/2021




PRINT

Oil level, checking

Preparatory work

Removing the lower engine cover




Slacken off the screws and remove the lower engine cover.

Removing air filter housing

Remove:

- the fresh air intake hose
- the air cleaner (ACL) housing assembly from its connections.




Before filling

Remove filler plug (Torx 55).

Suspend a filler syringe or a hose with funnel in the filler hole. Use transmission fluid: Lubrication transmission .

Caution! Make sure the hose is absolutely clean.

Caution! Make sure the hose cannot slip out of the filler hole.



Installing the air cleaner (ACL)

Put in place temporarily:

- the air filter
- the connector for the mass air flow (MAF) sensor.

Check

Basic fluid level check

Start the engine.

Note! Leave the engine running during the entire check.

Note! The following measure must be carried out quickly to avoid overheating the fluid.


Run through all the positions between P and D on the gear selector. Stop at each position for at least 2 seconds. Perform this process twice.

Place the gear selector in position P.

Raise the vehicle and place a receptacle under the gearbox.

While the engine is running, remove the integrated level plug (Torx 40).

If there is no transmission fluid coming out of the level plug hole, top up until it starts to drop.




Fit the integrated level plug (Torx 40) by hand. Reuse the old O-ring.

Switch off the engine.

To prevent the temperature exceeding the measuring interval in the next measure, top up with 0.5 litre transmission fluid as follows: Lubrication transmission .


Finishing

Installing the filler plug



Fit the filler plug (Torx 55). Use a new O-ring. Moisten the new O-ring with transmission fluid and tighten according to: Tightening torque .

Installing the air cleaner (ACL)



Install:

- the connector for the mass air flow (MAF) sensor
- the hose clip for air bellows.

Checking the oil level

Connect the diagnostic equipment and read the transmission fluid temperature continuously.

Start the engine.


Note! Leave the engine running during the entire check.

Note! The following measure must be carried out quickly to avoid overheating the fluid.

Run through all the positions between P and D on the gear selector. Stop at each position for at least 2 seconds. Perform this process twice.

Allow the transmission fluid to heat up to 50 °C.

Note! The fluid will not heat up faster by stalling.



Place a lower drip shield on the floor under the vehicle.

While the engine is running, remove the integrated level plug (Torx 40).


Allow the excess fluid to run out.

When the fluid is between 50 °C and 60 °C, check that the transmission fluid has stopped running out and is only dropping from the level plug hole.

Caution! It is essential the temperature not exceed 60 °C, as this can result in the transmission fluid level being too low.

Fit the integrated level plug (Torx 40). Use a new O-ring. Moisten the new O-ring with transmission fluid and tighten according to: Tightening torque .

Note! Wipe away any transmission fluid spill.



Installing the lower engine cover

Fit the lower engine cover with bolts, 6 x M8. Tighten.

Switch off the engine.



6/11/2021

PRINT