


Front door sill trim panel



Removing the sill trim panel

- Pull the sill trim panel to release the front clip (1)
- Angle out the front edge of the frame (2)
- Detach the rear edge
- Pull out.

Installing the sill trim panel

Install:

In reverse order.