




Fig. 11.16 Exterior handle link adjustment (Sec 18)

A *Latch stop*

B *Tongue protrusion*

C *Adjuster*