

Installing the front timing cover

Note! Ensure that the timing belt cover is in position before the cover is pressed in against the rear timing belt cover to prevent damage to the nipple on the thermostat housing.

Install:

- the front timing belt cover
- the hose between the thermostat housing and the expansion tank
- the surround, cover and air ducts for the control module box.

