


Relay and Fuse Board

1988 Volvo 740



- * A - Bulb Failure Warning Sensor Relay
- * B - Seat Belt Reminder/Key Warning Relay
- * C - Intermittent Windshield Wiper Relay
- * D - Intermittent Wiper Relay (Rear Tailgate - Wagon)
- * E - Fuel Injection Relay
- * F - Rear Window Defroster Timer Relay
- * G - Headlight Flasher
- * H - Gear Change Indicator Relay (Turbo)
- * I - Overdrive Relay
- * J - Overload Relay 15I (Power Windows/Seat Heater)
- * K - Headlight Relay
- * L - Central Locking Relay
- * M - Front and Rear Fog Lamp Relay
- * N - Overload Headlight High-Beam Relay
- * O - Not Used
- * P - Not Used
- * R - Not Used
- * S - Not Used