

873: Climate unit, B6304T2, L.H.D

Operation number:
87331-3




Operation number:
87346-2

Resistor - blower motor




Removal

Remove accelerator pedal

Refer to: Accelerator pedal



Note! Note the position of the component before removal.

**Installation**

To install, reverse the removal procedure.