




- A. Air Pump Relay
- B. Not Used
- C. Main Relay
- D. Not Used
- E. Not Used
- F. A/C Relay
- G. Fog Lamp Relay
- H. Not Used
- J. Ignition Coil Relay
- K. Starter Motor Relay
- L. Fog Lamp Relay
- M. Marker/Parking Lamp Relay
- N. Horn Relay

ENGINE COMPARTMENT RELAY/FUSE BOX