


Panel, tailgate, replacing

Removing the tailgate panel



- Remove the cargo compartment side panel.
See [Lower tailgate panel](#)
- Detach the two side clips by pulling the sides inwards
- Detach the four covered clips by pulling straight downwards (with the cover folded up completely).

Installing the tailgate panel

Install:

In reverse order.