

Ignition coil Diagram 1

Terminals	Condition	Typical value	Note
+ & -		0,4-0,8 Ω	1, 3

Notes

- 1. Checking primary resistance.
- 3. Separate ignition coil and amplifier.

Ignition coil Diagram 2

Terminals	Condition	Typical value	Note
+ & HT		2500-5500 Ω	2, 3

Notes

- 2. Checking secondary resistance.
- 3. Separate ignition coil and amplifier.

Diagram 1




Diagram 2

