

1996 850

For function diagram, see page 212.

Position	Terminal
Key Out	30
0	X
I	X
II	X
III	X

Terminal connections for the control unit (3/6):

- 30: X
- 15: X
- 15: X
- 50: X
- 50: X

