



Emission control ME7




Engine management system ME7




7/129	Brake pressure sensor 2	8/90	Solenoid, fuel tank CNG FR
7/130	Fuel level sensor, injector side	8/111	Solenoid valve, high-pressure diesel
7/135	Glass breakage sensor, LH		
7/136	Glass breakage sensor, RH	9/1	Front 12V outlet
7/137	Glass breakage sensor, tailgate	9/2	Heated rear window
7/139	Brake pressure sensor 1	9/12	Left seat heater
7/143	Fuel level sensor, pump side	9/13	Right seat warmer
7/149	Rain sensor	9/16	LH backrest heating element
7/153	Sensor, fuel level LPG	9/17	RH backrest heating element
7/156	Pressure and temperature sensor CNG	9/18	LH seat heating element
7/159	Air quality sensor	9/19	RH seat heating element
7/162	Pressure sensor, fuel line	9/25	Rear 12V outlet
7/164	Sensor module DSTC	9/30	Auxiliary heater
7/172	Position sensor, camshaft, intake side	9/32	PTC resistor - air preheating
7/173	Sensor, camshaft	9/33	LH heated door mirror
		9/34	RH heated door mirror
		9/38	Electrically heated fuel filter
8/3	Solenoid switch AC		
8/6-10	Injectors		
8/17	EGR valve	10/1	LH front lamp housing
8/18	EVAP valve	10/2	RH front lamp housing
8/19	Variable valve timing valve	10/3	License plate lighting
8/28	Turbocharger control valve	10/5	FL fog light
8/30	Driver side airbag igniter	10/6	FR fog light
8/31	Passenger side airbag igniter	10/11	FL parking light
8/32	Igniter, passenger side airbag stage 2	10/12	FR parking light
8/33	FL belt tensioner igniter	10/13	FL direction indicator
8/34	FR seat belt tensioner igniter	10/14	FR direction indicator
8/36	Shift lock solenoid	10/15	FL fender direction indicator
8/37	Automatic transmission	10/16	FR fender direction indicator
8/38	Shift solenoid 1	10/17	Lamp housing, RH tail light
8/39	Shift solenoid 2	10/18	Lamp housing, LH tail light
8/40	Lock-up solenoid	10/19	Auxiliary brake light
8/41	Pressure solenoid	10/25	Ceiling light, cargo compartment
8/44	Canister shut-off valve	10/29	Glove compartment lighting
8/46	DSTC activation module	10/43	RH brake light
8/51	FL side airbag igniter	10/44	RH tail light lamp 1
8/52	FR side airbag igniter	10/45	RH tail light lamp 2
8/55	RL belt tensioner igniter	10/46	Fog light, right rear
8/56	RR belt tensioner igniter	10/47	RR direction indicator
8/59	RL head restraint solenoid	10/48	RH reversing light
8/60	RR head restraint solenoid	10/50	LH brake light
8/61	Driver side airbag igniter step 2	10/51	LH tail light lamp 1
8/62	Belt tensioner igniter, center rear seat	10/52	LH tail light lamp 2
8/64	Solenoid valve, engine mounting	10/53	Fog light, left rear
8/66	LH inflatable curtain igniter	10/54	RL direction indicator
8/67	RH inflatable curtain igniter	10/55	LH reversing light
8/71	Throttle solenoid	10/64	RH high beam
8/72	Shift solenoid 3	10/66	RH low beam
8/73	Shift solenoid 4	10/68	LH high beam
8/74	Shift solenoid 5	10/70	LH low beam
8/75	Valve, fuel cut-off DFCO	10/114	LH vanity mirror lighting
8/76	Gas tank valve	10/115	RH vanity mirror lighting
8/79	Valve LPG	10/125	LH front courtesy lighting
8/81	Solenoid, variable valve timing outlet	10/126	RH front courtesy lighting
8/82	Solenoid, variable turbo geometry	10/129	FL parking light
8/84	Switch, vacuum pump	10/130	FR parking light
8/85	Thermostatic switch, fuel filter	10/142	FL door control module lighting
8/88	Solenoid, fuel tank CNG rear		
8/89	Solenoid, fuel tank CNG FL		

6/64	Passenger seat motor, backrest angle
6/65	Passenger seat motor, up/down front edge
6/66	Passenger seat motor, up/down rear edge
6/67	Pump, fuel leakage control
6/69	Damper motor, ventilation/floor/defroster


8/18




8/28



8/81



9/32



6/67

