

Calibrating the blower fan

- If the car is equipped with Manual (MCC) or Standard climate control, the blower fan speed must recalibrated if the battery has been disconnected
- Ignition on
- Turn the blower fan switch to maximum
- Turn the blower fan switch to minimum
- The calibration is complete.