


Relays/Shunts

Cargo compartment RMA1 - RSH6



Relays/Shunts in cargo compartment

Pos	Relay function
RMA1	Relay, 15l feed, rear 2/52
RMA3	Relay, heated rear window 2/82
RMI2	Unlocking relay, RL 2/112
RMI3	Relay, deadlock, rear doors 2/115
RMI4	Relay, reversing light 2/80
RMI5	Relay, brake lights 2/79
RMI6	Relay, rear fog light 2/49
RMI7	Relay, trailer fog light 2/83
RMI8	Relay, preheated fuel filter 2/142
RMI13	Relay, rear window wiper 2/72
RMI14	Relay, rear adjustable head restraint 2/75
RMI16	Relay, intermittent rear window wiping on/off 2/16
RMI17	Relay CNG/LPG 2/140
RMI19	Unlocking relay, tailgate 2/87
RMI20	Locking relay, rear doors, filler flap 2/158
RMI21	Unlocking relay, fuel filler flap 2/59
RMI23	Unlocking relay, RH rear 2/114
RSH2	Shunt, low beam REM 20/29
RSH3	Shunt, cargo compartment 12V outlet 20/39
RSH4	Shunt, parking light REM 20/28
RSH5	Shunt, parking light/tail light REM 20/33
RSH6	Shunt, brake light REM 20/31