


Front door



Remove the four mounting elements.
(Screws or blind rivets)
Lift out the lift mechanism.
Disconnect the connector.

Note! When drilling out blind rivets: [Removing rivets](#) .

Installation

Install:

In reverse order.


Note! Install new rivets in the numerical order illustrated.

Initializing the window position

The window position must be initialised after installation.

Ignition on.

Initialise. See [Checking the power window mechanism](#) .



This document was created with Win2PDF available at <http://www.win2pdf.com>.
The unregistered version of Win2PDF is for evaluation or non-commercial use only.
This page will not be added after purchasing Win2PDF.