

Drip guard

Replacing the drip guard



The drip guard is bonded into place.

Try to pull the drip guard away in one piece.

Note! Replace the drip guard if it is damaged.

The drip guard is secured by two blind rivets.

Note! Drill out one of the rivets then move the drip guard to one side.



Install:

In reverse order.

Rivet the drip guard into place.

Note! Always use new blind rivets, P/N 982565.