

Radiator, replacing

Note! The illustrations in this service information are used for different model years and/or models. Some variation may occur. However, the essential information in the illustrations is always correct.

Removal

Removing the engine cooling fan (FC)


Remove the engine cooling fan (FC) for engine B8444S in accordance with: [Engine cooling fan \(FC\), replacing](#).

Remove the engine cooling fan (FC) for other XC90 engines. See [Engine cooling fan \(FC\), replacing](#).

Removing the radiator

Remove:

- the evacuation hose from the expansion tank
- the 4 bolts



Remove:

- the 2 mounting bolts
- the radiator.



Installation

Installing the radiator

Lift the radiator. Install the two M8 mounting bolts.

Note! Ensure that the radiator is positioned correctly in the locating pins on top of the unit.

Note! Ensure that no hoses are trapped when installing the radiator.



Install:

- the evacuation hose from the expansion tank
- the 4 x M6 screws.

Installing the engine cooling fan (FC)

Install the engine cooling fan (FC) for engine B8444S in accordance with: [Engine cooling fan \(FC\), replacing](#) .

Install the engine cooling fan (FC) for other XC90 engines. See [Engine cooling fan \(FC\), replacing](#) .